


invue

Showcase Lock Removal Tool

PL451



Overview

Review entire instruction guide before removing lock.

Components

1. Showcase Lock Removal Tool (PL451)

Quick Start Overview

1. Unlock cabinet and open swing-out doors
2. Remove Showcase Lock

System Overview

Tool is used to remove Showcase Lock from swing-out door.




Caution:

Wear appropriate safety gear (gloves and eye protection) when working with and around glass cabinets.


1a

Unlock Showcase Lock with IR2 Key.



1b

Open door. Slide removal tool over lock. Rotate removal tool side to side along plane of glass to remove lock.



INVUE®

tough security made easy

www.invuesecurity.com

Corporate Office (North America) // 704.752.6513 • 888.55.INVUE

Europe, Middle East & Africa // +31.23.8900150

Asia Pacific // +852.3127.6811

Latin America // +52.55.9000.3957